

Kaiuttimet:

d&b C7 TOP
d&b C7 SUB
d&b Q1
d&b Q7
d&b Q-SUB
d&b Max 15"
Toa RS20
JBL C1
Near
DB Opera Live 40S

Aktiivikaiuttimet:

db L80

Vahvistimet:

d&b P1200
d&b D12
Crest CA4
Crest CPX 2600

Äänipöydät:

Yamaha LS9 (32)
Yamaha DM 1000 (16)
A&H GL 4000 (48)
A&H GL 3300 (32)
A&H GL 2200 (24)
Alto L16

Efektiprosessorit:

TC Electronic M-ONE
TC Electronic D-TWO
Lexicon MPX 500
Lexicon MPX 110
Yamaha SPX 90

Dynamiikkaprosessorit:

DBX 266 XL
DBX 1074
Drawmer MX4

Ekvalisaattorit:

XTA GQ 600
DBX IEQ 31
DBX 2231
DBX 1231

Kaiutinprosessorit:

DBX 480

DJ-laitteet:**Mikserit:**

Pioneer DJN-500
Pioneer DJN-600

CD/MD-soittimet:

Pioneer CDJ-1000
Pioneer CMX 5000
Gemini CD-9000
Pioneer CD/MD MXD-04
Pioneer CD PD204
MD-soitin Pioneer JE330
DAT-soitin Fostex D5

Mikrofonit:

Shure sm58
Shure beta 58A
Shure sm58s
Shure sm57
Shure beta 52
Shure beta 87A
Sennheiser MD421
Sennheiser 604
Sennheiser E835
Sennheiser E935
Sennheiser MD 409
Sennheiser E606
Sennheiser E906
Sennheiser E901
AKG D880
AKG D112
AKG se300/ck-91
AKG c451
Beyerdynamic Opus 88
Beyerdynamic Opus 87

Langattomat mikrofonit:

Sennheiser ew300 G2
Shure sm58 ut2/eut4
Shure SLX 4 (beta87A)
Shure SLX 4 (headset)

DI-boxit:

Ultra-Di
LDI 02
TDI 8-ch

Kaukokaapelit:

16+4 30m
32+4 35m
32 55m
32 30m

Backline laitteet:

Bassovahvistin Hartke HA3500
Bassokaiutinkaappi Hartke 410TP
Kitaracombo Fender Blues-Deluxe
Reissue

Oheislaitteet:

Melumittari AZ8922